














Surgical Technique Overview

<p>Step 1 Entry Point: Insert 3.2mm Guide Pin</p> 	<p>Step 2 Open canal with 16mm/12.5mm Reamer</p> 	<p>Step 3 Manually insert the INTERTAN Nail</p> 	<p>Step 4 Check Lag Screw position and anteversion. Fully seat Nail</p> 	<p>Step 5 Open lateral cortex with 4.0mm Trocar and 4.0mm Drill Bit</p> 	<p>Step 6 Insert 3.2mm Guide Pin Sleeve and 3.2mm Guide Pin. Measure for Lag Screw</p> 	<p>Step 7 Drill with 7.0mm Compression Screw Starter Drill</p> 
<p>Step 8 Drill with 7.0mm Compression Screw Drill</p> 	<p>Step 9 Insert Anti-Rotation Bar into Compression Screw slot</p> 	<p>Step 10 Drill for Lag Screw with Lag Screw Drill</p> 	<p>Step 11 Insert Lag Screw</p>  <p>Ex Set for 5mm of compression</p>	<p>Step 12 Remove Anti-Rotation Bar and insert Compression Screw</p>  <p>Ex Position after 5mm of compression</p>	<p>Step 13 Lock distally with 5.0mm Locking Screw</p> 	<p>Final View</p> 